


The Music players

Manufacturer's instruction books are not available

To operate the one in the Lounge:

Ensure the system is plugged in and switched on at the socket. Plug the stereo jack into the earphone socket of your i-Pod, phone, MP3 player tablet or whatever. Switch on at the small box and adjust the volume with the thumbwheel on the top of this box. Note the amount of bass can be adjusted by the knob on the back of the bass unit. Note that there is a headphone socket in the control box also.



To operate the one in the Kitchen:

The i-Pod dock in the kitchen can only be used with the older i-pods and i-phones having the original Mac connector. To use, plug in to the wall socket, switch on and then switch on the machine itself. Plug your i-phone or i-pod into the dock and operate with the remote.